

SLIDE-OUTS

Tools Required (Fig. 1)
Drill
1/4" Drill Bit
7/16" Wrench
9/16" Wrench

Fig. 1



1. Rotate the cross shaft 90 degrees and drill a new 1/4" hole (Fig. 2).

Fig. 2



2. Reattach motor and cross shaft using:
 - Bolt - 1/4" - 20 x 2 Cap Screw GR8 Yellow Zinc
 - Nut - 1/4" - 20 Top Lock GR2 Zinc

Fig. 3



As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lci1.com or by downloading the MyLCI app.