

LEVELING AND STABILIZATION

Purpose

To maintain and extend the product life of the Ground Control 3.0® product line.

Safety

WARNING

Failure to follow the instruction provided in this manual may result in death, serious personal injury, severe product or property damage or voiding of the component warranty.

WARNING

The trailer MUST be supported per the manufacturer's recommendations before working underneath. Failure to do so may result in death, serious personal injury, severe product or property damage or voiding of the component warranty.

WARNING

The coach should be supported at both front and rear axles with jack stands before working underneath. Failure to do so may result in death, serious personal injury, severe product or property damage or voiding of the component warranty.

CAUTION

Wear eye protection and any other appropriate personal protective equipment when performing maintenance.

CAUTION

Moving parts can pinch, crush or cut. Keep clear and use caution.

Resources Required

- Lint-free cloth
- Silicone lubricant

LEVELING AND STABILIZATION

Maintenance Steps

1. For optimum performance, the system requires full battery current and voltage. The battery must be maintained at full capacity.
2. Inspect and clean all terminals and other power unit electrical connections at the battery, controller and jacks every 12 months for corrosion and loose or damaged connections. If corrosion is evident, spray connections with electrical contact cleaner.
3. Remove dirt and road debris from jacks as needed.

WARNING

The coach should be supported at both front and rear axles with jack stands before working underneath. Failure to do so may result in death, serious personal injury, severe product or property damage or voiding of the component warranty.

4. If jacks are down for extended periods, it is recommended to spray exposed leveling jack rods with a dry silicone lubricant every 3 months for protection. If the trailer is located in a salty environment, it is recommended to spray the rods every 4 - 6 weeks.

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lci1.com or by downloading the MyLCI app.