


DOORS

Bauer NE Battery Installation (Fig. 1)


1. Carefully remove 2 (two) 4x40 screws (A).
2. Install 4 fresh AA batteries (B) according to the orientation symbols (C).
3. Install Battery Compartment Lid (D) by aligning the 3 tabs and 3 slots (E).
4. Carefully install the 4x40 screws to attach Battery Compartment Lid.



NOTE: Please enter your Personal Code (Fig. 2, Step. 4) upon installation of lock to prevent inadvertent programming.



Bauer NE Lock Operation (Fig. 2)

1. Touch the area next to the buttons to "Wake Up" the lock (F).
2. The Buttons will illuminate when the lock is "awake" and will be ready to accept the code.
3. The factory default code is 3, 7, 1, 5 and is followed by the Enter button (G).
4. Touch and hold the 3|4 button (H) and Enter button (G) for 2 seconds. The lock will beep 3 times to accept a new code. Enter a 4-digit code followed by the Enter button (G). The lock will beep 4 times to indicate a new code acceptance. This is now your new code.




LIPPERT
COMPONENTS

Lippert Components Inc.
Service and Warranty
(574)-537-8900
lci1.com

Bauer Products Inc.
1-866-68-BAUER (22837)
www.bauerproducts.com

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at customerservice@lci1.com. Self-help tips, technical documents, product videos and a training class schedule are available at lci1.com or by downloading the MyLCI app.