



Service Bulletin

82-S0515

September 29, 2009

NOTICE


Forced and/or reversed power and motor connections made during the replacement of room slide controls will result in a damaged control unit.

Room Slide Control Replacement (Installation Instructions)

Forced and/or reversed power and motor connections made during the replacement of the following room slide controls will result in a damaged control unit.

<u>Control Unit</u>	<u>Power Gear Part #</u>	<u>Winnebago Part #</u>
RPE FLS control	1510000154	171064-01-000
FLS Single control	1510000152	171064-02-000
RPE control	1510000151	171058-02-000
Single FLS control	1510000153	171058-01-000
FLS control	1510000180	171058-03-000

The battery (power) and motor harness receiving hole connection points (located between the 1st and 2nd blade connectors) are identified on the decal located on the control to ensure proper installation.



Effective October 1, 2009, Power Gear will no longer warranty parts and labor on replacement control units that are improperly installed.

For ease of installation, and to ensure proper connection, replace one harness at a time.