



**BETTER BATH® DECORATIVE
WALL PANELS
OEM INSTALLATION MANUAL**

L I P P E R T
C O M P O N E N T S®

Safety Information

LCI recommends that installations only be done by a qualified technician. LCI also recommends that the technician should use appropriate personal protective equipment, such as safety glasses and gloves, during the installation process.



Failure to follow the instructions provided in this manual may result in injury, component damage, or voiding of the component warranty.

Installation

NOTE: All caulks, adhesives, sealants **MUST** be compatible with ABS.

1. Construct alcove, alcove walls, and install shower pan per proper installation requirements. Alcove walls are to be clean, dry and free of any protruding objects (nails, staples, etc.) Ensure alcove walls are square and plumb for proper fit to shower pan.
2. Cover shower pan to protect surface and minimize clean-up. Panels are provided with a clear protective film to be removed after installation.
3. Corners of the alcove walls and top of shower pan flanges should be sealed to form a watertight joint.
4. Install back panel first.
 - A. Measure up from deck of shower pan 77" and mark alcove wall. Apply adhesive to the alcove wall within the measured area.
 - B. Install back panel, centered in alcove, with bottom edge of panel sitting on pan. Starting from the bottom, firmly press from center to edges and work upward. (If using a mastic adhesive requiring flashing, pull panel away from wall, reposition and repeat installation).
 - C. Remove protective film or peel edges of film back far enough to allow for installation of side panels. Do not use sharp instrument to cut film.
5. Install Side Panels:
 - A. Repeat instructions in step 4, with bottom edge of panel setting on pan and inside edge fitted flush against back pane. A tight fit against the back panel is essential.
6. Remove protective film from all panels.
7. Perimeter of the decorative panels, inside corners, and bottom of panels and deck of pan should be sealed to form a water-tight joint.
8. Decorative wall panels can be easily cleaned using mild soap and soft cloth. Minor scuffs and scratches can be buffed out using a non-abrasive polishing compound followed by a clean water rinse.

Care and Cleaning Instructions

LCI Thermoforming units are easy to keep clean and sparkling. Simply use warm water and a mild soap solution. Rub with a soft cloth and rinse thoroughly with warm water. Do not use abrasive cleaners or harsh chemicals.

Recommended Cleaners: Mild soap and water, Fantastic Spray Cleaner, Top Job Liquid (3% solution), Spic and Span Pine Cleaner, Joy Liquid Detergent (5% solution), Gel-Gloss, "The Works" Tub and Shower Cleaner, DuPont 7 Auto "Polish," and DuPont 606S Auto "Polish." All cleaning should be followed by a warm water rinse.

Do Not Use: Disinfectant sprays, disinfectant foams, pine oil cleaners, citrus-based cleaners, abrasive cleaners, harsh chemicals, Scrubbing Bubbles, petroleum-based products, auto rubbing compounds or industrial or commercial cleaners.



If any adverse chemicals, as described in the Care and Cleaning Instructions, come in contact with any surface, immediately rinse thoroughly with clean water.

With the exception of Permalux® and Permalux Plus® products, fading or discoloration may result from continued exposure to direct sunlight. Keep blinds or drapes closed during periods of the day when the product is exposed to direct sunlight.

Do not place any hot objects or objects such as candles or cigarettes on the surface of this product. These objects may scar, burn or ignite this plastic.



L I P P E R T C O M P O N E N T S™

The contents of this manual are proprietary and copyright protected by Lippert Components, Inc. ("LCI"). LCI prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized LCI representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of LCI.

Revised editions are available for free download from lci1.com.

Please recycle all obsolete materials.

For all concerns or questions, please contact
Lippert Components, Inc.

Ph: (574) 537-8900 | Web: lci1.com | Email: customerservice@lci1.com