

**Kwikkee**<sup>®</sup>  
**PRODUCTS**

by  Lippert Components<sup>®</sup>

**KWIKEE<sup>®</sup> STEP WELL COVER**  
**OWNER'S MANUAL**  
**(370932)**

# TABLE OF CONTENTS

<b>Introduction</b> .....	<b>2</b>
<b>Safety</b> .....	<b>3</b>
<b>Operation</b> .....	<b>3</b>
Extension .....	<b>3</b>
Retraction .....	<b>3</b>

## Introduction

**NOTE:** This information was obtained from Kwikiee® manual 1422194 Rev OE dated January 2009.

The Kwikiee® 90615 (LCI 370932) Series Step Well Covers are designed for front-entry coaches. The step well cover provides comfort and foot support for the person riding in the passenger seat. The step well cover also provides added user safety by preventing accidental falls into the entry step well.

The construction of the step well cover consists of three primary parts:

1. Outer Shell – The outer shell connects directly to the chassis of the motor coach and provides the structural support and environmental protection for the drive mechanism and slider.
2. Step Well Cover – The step well cover is the portion of the assembly that extends and that the user sees during normal operation.
3. Drive Mechanism – The drive mechanism is responsible for providing the power to drive the slider in and out.



## Safety

### **WARNING**

The “WARNING” symbol is a sign that precedes a service, maintenance or operational procedure containing a possible personal safety risk that could result in serious injury or death if stated safety precautions and procedural steps are not followed as set forth in this manual.

### **WARNING**

Failure to act in accordance with the following may result in death or serious personal injury. Read all operating instructions first before using your Kwikkee® Step Well Cover.

### **CAUTION**

Moving parts can pinch, crush or cut. Keep clear and use caution.

## Operation

### **WARNING**

Do not ride on the step well cover during operation.

## Extension

To extend the step well cover:

1. Make sure that there are no obstructions in the entry step well which will interfere with the operation of the unit.
2. Locate the step well slide rocker switch and position yourself fully inside the coach. Do not stand in the entry step well.
3. Press and hold the rocker switch in the extend position until the unit is fully extended and stops moving.
4. Verify that the step well cover is fully extended by visually checking to see that it is level and parallel to the main floor and that the front edge of the step well cover is resting on the support blocks next to the entry door.

## Retraction

To retract the step well cover:

1. Make sure there is nothing laying on top of the step well cover.
2. Locate the step well slide rocker switch and position yourself fully inside the coach.
3. Press and hold the rocker switch in the retract position until the step well cover is fully retracted and stops movement.
4. Verify that the step well cover is fully retracted by visually checking to see that it is flush with the back part of the step.



# L I P P E R T C O M P O N E N T S<sup>®</sup>

The contents of this manual are proprietary and copyright protected by Lippert Components, Inc. ("LCI"). LCI prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized LCI representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of LCI.

Revised editions are available for free download from [lci1.com](http://lci1.com).

Please recycle all obsolete materials.

For all concerns or questions, please contact  
Lippert Components, Inc.

Ph: (574) 537-8900 | Web: [lci1.com](http://lci1.com) | Email: [customerservice@lci1.com](mailto:customerservice@lci1.com)